



# Advanced performance

The Axiom AN offers unmatched reliability using non-contact position sensing with solid state electronics and contaminant-tolerant pneumatic control. Coupled with its space-efficient design, corrosion resistance and networking/Wireless Link capability, the AN offers unrivaled convenience and cost-saving benefits in hazardous and general purpose process applications.

#### **Exceptional reliability**

The proven technologies combined with efficient design and durable materials, delivers long life and exceptional performance.

- Survives harsh conditions
- Tolerates air contaminants
- Provides solid state position-sensing

#### **Universal application**

The strategic engineering reduces inventory and ensures universal adaptability in many applications and environments.

- · Universal voltage capability
- Selectable SR/DA action
- Direct actuator attachment


#### User-friendly advanced technology

Designed with the user in mind, the Axiom AN offers the utmost in ease and convenience.

- Rapid enclosure entry
- Easy configuration
- · Convenient wiring access
- Wireless Link app set up



See StoneL.com/approvals for current approvals.



Operates from 24 VDC – 250 VAC at extended temperate range and features manual override. Single or dual coil available.

#### Impact-resistant cover

Vapor tight, Lexan® cover screws off for rapid entry without tools. It withstands high-pressure wash downs and typical process environment corrosives.

#### **Convenient settings**

Touch pad enables position settings to be conveniently locked in. Switch settings remain in place during power cycling.

#### High flow pneumatic valve

5-way, 2-position valve operates on standard plant air. Rebreather prevents ingestion of contaminated air into actuator.

#### **High visibility** indication

Mechanical and electronic indication confirms open and closed position. Intense LEDs display position status from a distance.

#### SR/DA plug

Plug positions into designated port to enable spring return or double-acting operation.

#### **Direct actuator attachment**

Compact mounting manifold system requires less space and wiring, connects to VDI/VDE 3845 (NAMUR) actuators and adapts to spring return or double-acting actuators.


CLOSED

#### Fully sealed module

Solid state, fully potted sensors provide protection against residual moisture, vibration, and corrosives.

#### **Exceptional long life**

Magnetic position sensor has no bushings or shafts to wear out, delivers reliable performance, and is unaffected by actuator shaft wear.



# User-friendly advanced technology

#### Convenient switch setting

The touch sensors have no moving parts; just hold your finger for two seconds on the button to set. The bright LED indication confirms that you have successfully set the position. Communication models allow you to configure and set the sensors using your smart phone or tablet; no cover removal neededl

#### Reliable position sensing

An extremely reliable solid state magnetic resistive (mag res) sensor detects the valve position by monitoring the orientation of a magnet attached to the actuator. This design is tolerant of lateral and vertical shaft movement, which may occur in heavily used actuators, without affecting rotational measurement.

#### Easy everything

You will save maintenance time and trouble with the user-friendly design offering easy attachment, easy cover removal, easy access to wiring right on top, easy access to internal pneumatic manual overrides and easy component replacement.

#### Single or dual pilot configuration

The Axiom AN is available in either single or dual pilot configurations. Dual pilot options are available for shuttle piston, fail-in-last position applications. Several external manual override options are also readily available. For special valve configurations with nonstandard manual override features, please consult StoneL.

#### **High-visibility LED indication**

Clearly view valve position status with the high-visibility LED indicators. The LEDs offer easy viewing from a distance with the high intensity lighting that can be identified even in sunlight.

#### **Networking with Wireless Link**

Both the AS-Interface and DeviceNet models offer dramatic installation cost savings and have optional Wireless Link, with an iOS app. This feature offers unrivaled convenience and maintenance savings during the automated valve's entire life cycle. You may remotely access your valves from up to 50 meters, depending on obstructions.








Pneumatic manual override is conveniently located on top for easy access.



Touch sensors and LED indicators make set up fast and easy.



No cams, shafts or seals - offering exceptional vibration tolerance and nothing to wear out.

# Universal application

The Axiom is designed to readily adapt to most quarter-turn actuators. The mounting manifold system combines the mounting base and pneumatic manifold to minimize space and simplify installation. It attaches the Axiom directly to the actuator and ports air from the pneumatic valve to the actuator.

#### Included in the manifold system are:

- 1. Actuator shaft adaptor and fastener.
- 2. Epoxy-coated anodized aluminum mounting plate manifold with o-rings and stainless steel fasteners.
- 3. Pneumatic plug for SR/DA configuration.


The manifold system readily adapts to VDI/VDE 3845 sizes 1, 2 and 3. Special variations may be made for sizes 3, 4 and non-standard quarter-turn actuator mounting patterns.



The Axiom AN's compact size requires less than 5" of clearance.



The mounting manifold system is specified and sold separately. Kits are specific to actuator manufacturer. For kit numbers visit: StoneL.com/mounting.




#### Integral pneumatics

The Axiom's pneumatic valve system consists of a solenoid pilot that drives the main high-flow spool valve. Pilots are automatically associated with the appropriate function selected.

#### **Special features**


- Solenoid pilot and main spool design offer long life, exceptional tolerance to dirty air, and tight shut-off.
- Universal voltage solenoid system may be used for standard AC or DC applications.
- Five-way, two-position spring return configuration may be used for either single- or double-acting actuators. Dual coil shuttle piston versions are also available for fail-in-last position.
- Rebreather channels exhausted air from pressurized side of actuator into spring side, preventing ingestion of contaminated air from the environment that may corrode springs or actuator internals.



General pneumatic valve specifications				
Valve design		Pilot operated sp	ool valve	
Configuration		Single pilot Dual pilot	5-way, 2-position, spring return 5-way, 2-position, shuttle piston	
Flow rating		0.8 Cv 1.2 Cv		
Axiom porting		1/4" NPT (0.8 Cv) 3/8" NPT (1.2 Cv)		
Manifold porting		1/4" NPT		
Operating pressure		45 psi to 120 psi	(3.1 to 8.2 bar)	
Operating temperature		-40° C to 80° C (-4	40° F to 176° F)	
Operating life		1 million cycles		
Manual override			ary I momentary available I latching available	
Materials of construction	Spool Body Seal sp Spool O-ring End-ca	seals	Nickel plated aluminum Epoxy-coated anodized aluminum Polysulfone Nitrile compound Nitrile compound Nickel plated aluminum and stainless steel	
Solenoid coil specifi	cation	ıs		
35 Operating voltage Power consumption Inrush current Filtration requirements	40 - 250 VAC; 20 - 20 mA @ 40 - 250		) VAC (1.1 watts typical) VDC (0.5 watts typical @ 24 VDC)	
45 Operating voltage Power consumption Filtration requirements		12 - 24 VDC (output of barrier) 0.5 watts @ 12 VDC; 1.0 watt @ 24 VDC 50 micron		
92 & 97 Operating voltage		24 VDC		

# Single or double-acting configuration

The same Axiom AN model is suitable for both single-acting/spring return (SR) and double-acting (DA) actuators. The standard rebreather capability for single-acting/spring return is built in. Field configuration may be made by conveniently removing and reinserting the plug for the appropriate actuator type. For rebreather to function properly, both manifold ports must be tubed to the actuator.



0.5 watts

50 micron

Power consumption Filtration requirements


# Proven sensing and communication

The Axiom platform has all position sensing, communication or switching integrated into StoneL's C-module. Users may set open/closed positions conveniently and accurately on all modules. And easy to view instructions, along with bold LED indication, are displayed on the module itself.

#### Continuous sensing with open/closed settings


The C-module (continuous sensing) integrates a magnetic resistive sensor system to monitor exact valve position throughout the rotational range. Touch-sensitive or remote open and closed position setting along with microprocessor based operation make this state-of-the-art system convenient, reliable, and smart.

Position settings are made using the touch-sensitive buttons on the module's overlay. Simply operate the actuator to the open position (using standard internal manual override) and touch the SET OPEN button. Operate the actuator to the closed position and touch the SET CLOSED button. Position settings remain locked in when power is removed and reapplied.



#### Conventional I/O network

Valve monitors and valve controllers are often controlled and monitored using conventional I/O. In these cases, the position feedback is wired back to a PLC/DCS discrete input (DI) card. The solenoid valves are wired to and operated by a discrete output (DO) card. The Axiom solid state sensors are designed to work with the vast majority of DI/DO cards enabling compatibility with most PLC/DCS systems and a wide array of different voltages.






Switching and sensor specifications		
NAMUR sensor (45S)		
Configuration	(2) NAMUR sensor	s (EN 60947-5-6; IS)
Voltage range	5 - 25 VDC	
Current ratings	Target present Target absent	current < 1.0 mA current > 2.1 mA
Use with intrinsically safe rep	eater barrier. NAMUR se	ensors conform to EN 60947-5-6 standard.
Intrinsically safe solenoid	coil	
Voltage	12 - 32 volts from (	output of solenoid barrier to coil*
*Note: Use of an intrinsically safe solenoid barrier with internal impedance, or end-to-end resistance, of $\leq$ 500 ohms required for proper solenoid coil operation.		
Wiring diagram (45S)  NAMUR  Solenoid Valve	SOL1 OUT - e SOL1 OUT +	SOL PWR + SOL PWR - not used OPEN + OPEN - not used CLOSED + CLOSED -


#### Communication (bus) network

In a communication network system many devices, such as valve communication terminals and other process instruments, can be connected to a single cable back to the DCS/ PLC. Power and signal for all of the devices is carried over the network. Each device has its own address and it may have several I/O points.

AS-Interface is a versatile, low cost alternative to traditional hard wired I/O. It can replace traditional point-to-point wiring with a better, more flexible solution that is easier to install, operate and maintain and easier to re-configure. DeviceNet is another versatile, cost saving alternative to traditional hard wired I/O. It can replace traditional point-to-point wiring with a better, more flexible solution that saves money on installation and maintenance.



Valve Communication  DeviceNet™ communication	on Terminal (VCT) specifications	
Communication protocol	DeviceNet™	
Configuration	(2) Discrete inputs (sensors) (1) Auxiliary analog input (4-20 mA) (2) Discrete outputs (solenoids)	
Input voltage	11 - 25 VDC via DeviceNet™ network	
Output voltage	24 VDC	
Analog input impedance	254 ohms	
Quiescent current	No analog input, no outputs energized: 35 mA @ 24 VDC; 57 mA @ 11 VDC	
Maximum output current	150 mA (all outputs combined)	
Default address	63 (software assigned)	
Default baud rate	125K (software selectable 125K, 250K or 500K baud)	
Messaging	Polling, cyclic and change of state	
DeviceNet™ type	100	
Wiring diagram (925 & 92W) <b>DeviceNet</b>	not used Ain Ain +	
Solenoid Valve S	SOL 1 OUT -	









Conventional iPhone® and iPad® devices may be used. Contact StoneL regarding additional devices and special enclosures to make these devices suitable for use in hazardous locations.



Customize the tag for a device, change the address, force the solenoids on or off, wink the device, and set the valve limits.




Store and view additional information about a specific valve.



View real time valve position, cycle count, cycle timing, current valve temperature, error status, and more.

# Easily access hard-to-reach automated valves

Discover convenient remote access of your automated valves when you install the Axiom AN with AS-Interface and DeviceNet featuring *Bluetooth®* technology. Devices may be remotely accessed from up to 50 meters depending on obstructions. Setting changes and solenoid control are enabled through the DeviceNet or AS-Interface network or by the AS-Interface power supply jumper.




### Benefits of Wireless Link

- 1. Fast, convenient set-up for valve automation suppliers without special equipment.
- 2. Electronically enter and store key automated valve system information including:
  - End user tag number/information
  - Valve and actuator identification as well as Axiom model and serial number (Axiom information preset from factory)
  - Maintenance log.
- 3. Improve safety by easily accessing hard-to-reach automated valves without putting plant personnel at risk.
- 4. Reduce network commissioning time by accessing the VCT address and making changes if necessary.
- 5. Reduce maintenance time by monitoring valve cycle count, cycle times, storing maintenance logs, and accessing multiple valves from one location.
- 6. Conveniently retrieve installation manuals and access StoneL website when connected to Internet.

Specifications for Wireless Link		
Communication	Bluetooth® technology; single mode (not compatible with Bluetooth Classic)	
Transmit power	4dBm or ~2.5 milliwatts	
Data rate	1 Mbit/second; effective information transmit rate ~10 Kbits/second	
Range	Up to 100 meters (330 feet) in free space. Range is reduced by obstructions between hand-held device and Wireless Link VCT. Line of site is not necessary.	
Registrations	FCC, IC, CE	
CE compliance	Exceeds industrial compliance standards	
VCT identification	VCTs in range will be displayed in order of signal strength	
VCT link	One device accessed at a time between client (hand-held device) and server (VCT). Each server accessed by one client at a time	
Application	StoneL Wireless Link available from the App store	
Hand-helds	Compatible with iPhone® and iPad® with iOS 8 or later	

+1 218 739 5774 Valve communication & control | **11** 




## Visual indicator designations

Clearly view valve position status from up to 75 feet with the Axiom's visual indicator. The indicator's rugged Lexan® construction makes it resistant to physical damage and tolerant to most corrosives.



Designation	0°	90°
R	Red closed	Green open
G	Green closed	Red open
1	A → B	A B
2	A ♥ B	A B
X	Specialty configuration -	- please consult factory


# Dimensions



<sup>\*</sup> Aluminum cover 4.90 in [125 mm]

Specifications	
Materials of construction	
Housing and air manifold plate	Epoxy-coated anodized aluminum
Visual indicator drum	Nylon
Visual indicator cover	Polycarbonate
Fasteners	Stainless steel
O-rings	Nitrile compound
Operating life	1 million cycles
Temperature range	-40° C to 80° C (-40° F to 176° F)
Warranty	
Sensing and communication module	Five years
Mechanical components	Five years
Unit weights	
Aluminum	2.38 kg / 5.25 lb
Unit dimensions	
Unit height Cover removal clearance	122 mm [4.81 in] 214 mm [5.80 in]

Position sensing	
Accuracy	Within 1°
Repeatability	Within 1°
Setting buffer	4° from setpoint (Rotational distance from original setpoint where switch will energize on return stroke)
Dead band	6° from setpoint (Rotational distance from original setpoint where switch will de-energize)
Max rotational range	120°
Ratings	
Nonincendive (Class I and II, Div. 2)	All models*
Intrinsically safe (Ex ia Zone 0; Class I and II, Div. 1)	Function 45S only*
Enclosure protection	
Type 4, 4X and 6	All models
Ingress Protection 66/67	All models
Approvals*	See StoneL.com/approvals
* Only models listed on StoneL's	s official website are approved per specific rating.





# Robust testing of all components.

#### Mechanical



Acids

Actuator shaft eccentricity

Aging effects

Caustic mixtures

Chlorine

Conduit strength

Cycle life

High pressure spray

Icing

Impact resistance

Ingress protection

Operational positions

Organic oils

Organic solvents

Petroleum based substances

Salt fog

Steam pressures spray

Submersion

Temperature extremes

Ultraviolet tolerance

Vibration

#### **Electrical**



Circuit heat rise

Current and voltage limits

Cycle life

Electrostatic discharge immunity

Leakage current

Network protocol compatibility

Operational positions

Over current protection

Position sensor accuracy

(triggering, dwell, dead band)

Power cycling

Radio frequency interference

Reverse polarity

Temperature extremes

Thermal cycling

Thermal shock

Vibration

Voltage tolerance

#### **Pneumatic**



Cycle life

Dirty (solids) air tolerance

Flow rate

Housing pressure relief

Oils tolerance

Operation on nitrogen

Operational positions

Pressure limits

Temperature extremes

Vibration

Water tolerance

### Install with confidence



Hazardous location compliance



Built to last with reduced maintenance



Optimized performance

Proven performance from the inside out









Metso is a leading process performance provider, with customers in the process industries world wide. Metso's cutting-edge services and solutions improve the availability and reliability in minerals processing and flow control, providing sustainable process and profit improvements. Metso employs approximately 12,000 industry experts in 50 countries. Expect results.

www.metso.com



#### Metso Flow Control Inc.

Vanha Porvoontie 229, P.O. Box 304 FI-01301 Vantaa Finland Tel. +358 20 483 150, fax +358 20 483 151

North America Corporate Office 44 Bowditch Drive, P.O. Box 8044 Shrewsbury, Massachusetts, 01545-8044 USA

Tel. +1 508 852 0200, fax +1 508 852 8172



**Valve Communication Solutions** 

26271 US Highway 59, Fergus Falls, MN 56537 USA

Tech hotline +1 218 737 0701 Tel. +1 218 739 5774, fax +1 218 739 5776

Email: sales@stoneL.com **StoneL.com** 

Publication Number VP-713-12/16m ISO 9001

CERTIFIED StoneL