

CPI™ Single Ferrule Tube Fittings

For use on instrumentation, process and control systems, analyzers, and environmental equipment



Problems with incorrectly installed tube fittings ? CPI™ tube fittings are designed to provide three easy components for the installer-nut ferrule and body. You simply insert the tube, bottom it out, turn the nut 1 ¼ turns from finger tight and the CPI™ is properly made up. No extra ferrules, no different make up instructions, no extra places to seal.



Contact Information:

Parker Hannifin Corporation
Instrumentation Products Division
1005 A Cleaner Way
Huntsville, AL 35805

phone 256.881.2040
fax 256.881.5730
ipdsales@parker.com

www.parker.com/ipdus



Product Features:

- Single Ferrule
- Supercase Technology
- Superior Seat Finish
- Nut Lubrication
- Heat Code traceability
- Wide size range

Product Benefits:

- Excellent vibration and temperature compensation and the integrity of two seal points
- Corrosion resistant ferrule
- Enhanced body to ferrule seal
- Molybdenum Disulfide coated nut reduces make up torque and provides consistent remakes
- All stainless steel components are fully traceable with the chemical and physical documentation of the material
- Available in sizes from 1/8" to 2" in all configurations

ENGINEERING YOUR SUCCESS.