PINCH VALVES, COMPACT 3-WAY SOLENOID

- The 384 Series is a 3-Way universal solenoid-operated pinch valve designed for use with highly aggressive or high-purity liquids in analytical and medical instrumentation, and industrial applications
- Hermetic separation of control mechanism and the fluid within the tubing prevents particulate contamination caused by friction of moving parts, assuring maximum purity of liquids
- Available in a large range of body sizes to accommodate a wide variety of tubing sizes
- Removable and rotatable electrical coils allow for easy installation and worry-free maintenance
- Bi-directional flow for exceptional versatility
- Meets all relevant CE directives, and is RoHS compliant
- Typical applications include:
 - Hemodialysis
 - Urinary Collection Systems,
 - Intravenous (IV) Systems
 - Drug Dispensing

Fluids*	Temperature Range					
Air, Inert Gases, Water, Oil or Liquids	0 °C to 50 °C (32 °F to 122 °F)					

* Ensure that the compatibility of the materials in contact with the fluids is verified


General Valve Information*							
Body	Aluminum, anodized	POM (Graphite-reinforced polyacetal)					
Pinch Mechanism	POM (Graphite-reinforced polyacetal)						
Others	Stainless Steel						
Guide Tube	Nickel-plated Brass						
Coil frame		Galvanized steel					
Recommended Tubing	VMQ (silicone) (max. hardness: 50 Shore A) (Tubing not supplied with valve)	VMQ (silicone) (max. Hardness: 50 Shore A) 30cm (12in) tubing supplied with valve					

Electrical Characteristics


	A lesse testing to a she	DOM hash	
	Aluminium body	POM body	
Coil Insulation Class	F	F	
Connector	Spade plug; cable Ø4-6mm (0.16-0.24in), Ø6-10mm (0.24-0.40in)		
Connector Specification	4 W/8 W/6 W (DMX); DIN 43650, 9.4 mm, industry standard B; 6 W/13 W (AMX/FNX); ISO 4400/EN 175301-803, form A	305mm (12in) Lead Wires	
Electrical Safety	IEC 335	IEC 335	
Electrical Enclosure Protection	Coil type 01 = IP65 / Coil type 02-03 = IP65	IP30 (EN 60529)	
Standard Voltages1	12 VDC, 24 VDC	12 VDC, 24 VDC	
Power Consumption	4W, 6W, 8W, 9W, 13W	3.5W	
Response Time	< 20ms	< 10ms	



3/2 Universal




USE IN INTERMITTENT SERVICE Minimum waiting time between each application of power



1 Other voltages on request

	I	Powe	r Rati	ings	Ambient	Ambient			
Prefix Option	Inrush	Holding Hot/Cold		Hot/Cold	Temperature Ranges	Replace	Type ²		
	VA	VA	W	W	°C (°F)	12 VDC	24 VDC		
				4		43005268	43005269		
				8	10 1 - 00	500701-001	500701-002	01 (DNX-4)	
SC	-	-	-	6	-10 to 60 (14 to 140) -	500701-003	500701-004		
				9		43005143	43005144	02 (AMX)	
				13		43005316	43005317	03 (FNX)	





01086GB-2019-R01


PINCH VALVES, COMPACT 3-WAY SOLENOID

Specifications											
Tube I.D.	Tube O.D.	Pinch Force	Operating Pressure bar (psi)			Power Rating		Catalog Number			
		TOICE		ma	х.	110	natility		1		
mm (inches)	mm (inches)	daN	min.	inert gases	liquids	w		Aluminium body	POM body		
initi (inchec)		Guit		mort guoco	inquiuo			Aluminum bouy	24 VDC	12 VDC	
0.76 (0.030)	1.65 (0.065)	0.12	0	0.8 (11.6)	0.8 (11.6)	-	4	SCH384B004	-	-	
1.02 (0.040)	2.16 (0.085)	0.18	0	0.8 (11.6)	0.8 (11.6)	-	4	SCH384B001	-	-	
1.57 (0.062)	3.18 (0.125)	0.22	0	0.8 (11.6)	0.8 (11.6)	-	8	SCH384B0023	-	-	
1.98 (0.078)	3.18 (0.125)	0.18	0	0.8 (11.6)	0.8 (11.6)	-	6	SCH384B003 ³	-	-	
3.4 (0.132)	4.7 (0.183)	0.4	0	0.8 (11.6)	0.8 (11.6)	-	9	SCH384A005	-	-	
4.8 (0.187)	7.9 (0.313)	0.85	0	0.8 (11.6)	0.8 (11.6)	-	13	SCH384B006	-	-	
6.4 (0.250)	9.5 (0.375)	1.1	0	0.8 (11.6)	0.8 (11.6)	-	13	SCH384B007	-	-	
1.6 (0.063)	3.2 (0.126)	0.22	0	1.5 (21.8)	1.5 (21.8)	-	3.5	-	P384A024LCA00V1	P384A024LCA00V3	
1.6 (0.063)	3.2 (0.126)	0.22	0	1.5 (21.8)	1.5 (21.8)	-	3.5	-	P384A025LCA00V14	P384A025LCA00V34	

³ Observe the minimum of time stated, see graph above ⁴ The flange is rotatable with 90° (please see "Pic. 2" on following page)

How to Order


Aluminum body





PINCH VALVES, COMPACT 3-WAY SOLENOID

Dimensions (Aluminium body): mm (inches)



¹ Including coil(s) and connectors

Options (Aluminium body)

- · Flexible tubes having to use an external guiding device for optimum support (see dimensions):
 - With an outside diameter lower than 2.2mm (0.087in) (catalog numbers SCH384B001 to .. B004)
 - With an outside diameter lower than 3.5mm (0.138in) (catalog number SCH384A005)
 - With an outside diameter lower than 6mm (0.240in) (catalog numbers SCH384B006 and ..007) Contact us for information regarding the usage of
 - different tubing other than those recommended
- Plug with visual indication and peak voltage suppression or with cable length of 2m (78.7in)

Installation (Aluminium body)

- The solenoid valves can be mounted in any position without affecting operation, however, for optimum performance it is recommended that they be fitted with the solenoid operator at the top
- · Fixing plate built in between the body and the coil for assembly in a bank on a base plate
- Flexible tubes are not included in our supply
- In case the tubing is not placed in its seat, the solenoid valve could operate incorrectly.




71


SERIES

384

PINCH VALVES, COMPACT 3-WAY SOLENOID

Dimensions (POM body): mm (inches)






Ø16 (0.63)

26 AWG TEFLON COATED LEAD WIRES 12" LONG


> 11 (0.43)

> > 6 (0.24)

Tube Guiding Device



Arrangement for Wall-fitting



Weight ¹	Tube Gui	ding Device
kg	Catalog	Weight ¹
0.04	Number	kg
0.04	25978-01	0.005
		kg 0.04 Catalog Number

1 Including coil(s) and connectors

Options (POM body)

 \square

• Flexible tubes having to use an external guiding device for optimum support (see dimensions):

3 (0.12)

18.6 (0.73)

50.1 (1.97)

- With an outside diameter lower than 2.2mm (0.087in)
- Contact us for information regarding the usage of different tubing other than those recommended

Installation (POM body)

- The solenoid valves can be mounted in any position without affecting operation, however, for optimum performance it is recommended that they be fitted with the solenoid operator at the top
- Fixing plate built in between the body and the coil for assembly in a bank on a base plate
- In case the tubing is not placed in its seat, the solenoid valve could operate incorrectly.

